

VARIOspeed® N1

User Manual


This VARIOspeed® N1 controller is designed to provide constant pressure control for your pumping system.

Should you need to make minor adjustments, please consult the parameter table enclosed in this document.


Consult the factory for assistance.



Pressure Booster Pump Application



Deep Well Submersible Pump Application



⚠️ WARNINGS

Failure to read and understand the information provided in this manual may result in personal injury or death, damage to the product or product failure. Please read each section in its entirety and be sure you understand the information provided in the section and related sections before attempting any of the procedures or operations given.

Failure to follow these precautions could result in serious injury or death. Keep these instructions with warranty after installation. This product must be installed in accordance with National Electrical Code, ANSI/NFPA 70 so as to prevent moisture from entering or accumulating within the controller housing. See additional specifications on page 3 of this manual.

⚠️ WARNING



ELECTRICAL SHOCK HAZARD

Disconnect power to the VARIOspeed® N1 VFD and wait 10 minutes before removing the VFD cover.

A qualified service person must install and service this product according to applicable codes and electrical schematics.

- Lethal voltages are still present inside the VARIOspeed® N1 VFD after power is disconnected. Wait 10 minutes to allow internal capacitors to fully discharge before attempting to connect or disconnect wire or to service this equipment.
- Do not connect incoming power to motor terminals U, V, W. Doing so will result in irreversible damage to the drive.
- Do not connect power to this equipment if it has been damaged or has any missing parts.
- Verify that the incoming voltage supply matches the VFD rating before applying power to the unit.
- The VARIOspeed® N1 VFD contains no serviceable parts, do not attempt to repair this equipment.
- The VARIOspeed® N1 VFD must be grounded at the grounding terminal according to N.E.C. Refer to the electrical connection on page 12.
- Do not install in areas with: excessive or conductive dust, corrosive or flammable gas, excessive heat, regular impact shocks or excessive vibration.
- Do not install in areas where ambient temperature exceeds 40°C (104°F).

⚠️ WARNING



EXPLOSION OR FIRE HAZARD

Do not use this product with flammable liquids. Do not install in hazardous locations as defined by National Electrical Code, ANSI/NFPA 70.

Specification/Selection

| PART NUMBER | DESCRIPTION | MODEL | OUTPUT AMPS | HP | INPUT PHASE | OUTPUT PHASE | SHIP WEIGHT |
|-------------|----------------------|--------------|-------------|--------|-------------|--------------|-------------|
| 1041350 | VARIOspeed® N1, 240V | VS21-7.0-N1 | 7.0 | 1.5 | 1 | 3 | 21 lbs. |
| 1041351 | VARIOspeed® N1, 240V | VS21-10.0-N1 | 10.0 | 3 | 1 | 3 | 22 lbs. |
| 1041352 | VARIOspeed® N1, 240V | VS23-16.5-N1 | 16.5 | 5 | 3 | 3 | 21 lbs. |
| 1041353 | VARIOspeed® N1, 240V | VS23-31.8-N1 | 31.8 | 7.5-10 | 3 | 3 | 31 lbs. |
| 1041354 | VARIOspeed® N1, 240V | VS23-45.0-N1 | 45.0 | 15 | 3 | 3 | 38 lbs. |
| 1041355 | VARIOspeed® N1, 240V | VS23-58.0-N1 | 58.0 | 20 | 3 | 3 | 38 lbs. |
| 1041356 | VARIOspeed® N1, 480V | VS43-16.0-N1 | 16.0 | 7.5-10 | 3 | 3 | 31 lbs. |
| 1041357 | VARIOspeed® N1, 480V | VS43-29.5-N1 | 29.5 | 15-20 | 3 | 3 | 38 lbs. |

Note: HP rating is based on standard NEMA B 4-pole motor (used for indication only, use nameplate FLA for sizing). The output voltage of the VFD cannot exceed the incoming voltage. Example: 208V in, 208V out (max).

Selecting the Correct VFD

1. Determine the voltage available on site.
2. Select a pump with the same voltage (motor must be 3 phase).
3. Check pump motor nameplate Full Load Amps (FLA) for proper VFD sizing.
4. Select a VFD with an output amp rating higher than motor FLA.
5. Use motor Service Factor Amps (SFA) for submersible well pump applications for VFD sizing.

Phase Conversion

It is possible to supply single phase 240V input power to VS23 models. The VFD output amp must be derated by 50%. Example: The VS23-45.0-N1 will be derated to 22.5A output (max).

*Use three-phase input power if available. VS23 VFD's are not UL listed with single-phase supply. Always use a 3 phase motor.

Maximum Motor Cable Lengths

For 208V-240V pumps: 400 ft. For cable lengths greater than 400 ft., use a load reactor. Do not exceed 800 ft.

For 480V pumps: 50 ft. For cable lengths greater than 50 ft., use a load reactor. Do not exceed 300 ft.

Line/Load Reactors (Indoor/outdoor rated. Supplied separately.)

A Line Reactor is connected between the line power and VFD input. It is used for VFD protection and noise reduction.

A Load Reactor is connected between the VFD output and the motor. It is used for motor protection and noise reduction.

Mount reactors as close as possible to the VFD. Reactors will increase voltage drop, and may impact pump performance. Consult factory for selection.

| PART NUMBER | LINE/LOAD REACTORS | USE WITH MODEL | DIMENSIONS AxBxC (inches) | ELECTRICAL DATA | SHIP WEIGHT |
|-------------|--------------------|---|---------------------------|-----------------|-------------|
| 1041535 | LR23-16.5-N3R | VS21-7.0-N1, VS21-10.0-N1, VS23-16.5-N1 | 12X12X10 | 18A, 0.8mH | 37 lbs. |
| 1041536 | LR23-45.0-N3R | VS23-31.8-N1, VS23-45.0-N1 | 12X12X10 | 55A, 0.27mH | 46 lbs. |
| 1041537 | LR23-58.0-N3R | VS23-58.0-N1 | 12X12X10 | 83A, 0.17mH | 47 lbs. |
| 1041538 | LR43-16.0-N3R | VS43-16.0-N1 | 12X12X10 | 21A, 1.8mH | 38 lbs. |
| 1041539 | LR43-29.5-N3R | VS43-29.5-N1 | 12X12X10 | 35A, 0.71mH | 41 lbs. |

Enclosure (up to 5HP) measures 14.54 x 8.36 x 8.70 inches (36.93 x 21.23 x 22.10 cm) steel NEMA 1 for indoor use with locking latch.

Enclosure (above to 5HP) measures 18.54 x 10.36 x 10.74 inches (47.09 x 26.31 x 27.28 cm) steel NEMA 1 for indoor use with locking latch.


Environmental

Operating temperature: 14°F to 104°F (-10°C to 40°C)

Storage temperature: -4°F to 131°F (-20°C to 55°C)

Altitude: Maximum of 3280 ft (1000m) above sea level


Display Features and Navigation




Programming Examples

Changing the Motor Overload Amps

1. From the main display, press the Left or Enter button to enter the settings menu.




2. Rotate the rotary selector until the selection arrow highlights "Set Motor OL Amps".




Programming Examples


3. Press the rotary selector to enter Overload Amps editing.



4. Rotate the selector to begin editing the value. Pressing the left arrow button will move the editing position left one digit. This is useful when making large adjustments to the edited value quickly.



5. Press the rotary selector to save the edited value and exit the editing screen. Or press the ESC button (escape) to exit the editing screen without saving.



6. If no further setting needs to be edited, press the ESC button to return to the main display.



SETUP PARAMETER + LOG MENU

| | | |
|---------------------|---------------------|-----------------------|
| Set Pressure | Set PID Prop Term | Set High Press Alarm |
| Set Start Diff Pres | Set PID Integ Term | Set Run Dry Press |
| Set Motor OL Amps | Set 1st Accel Time | Set Run Dry Delay |
| Set Motor Voltage | Set 1st Decel Time | Set Run Dry Restart |
| Set Sleep Frequency | Set Accel 2 Sw Freq | View Run Time |
| Set Sleep Time | Set Acc/Dec Time | View VFD Fault Hist |
| Set Xducer Max Rng | | View System Fault Log |
| Set Min Frequency | | |
| Set Max Frequency | | |


OFF/AUTO Operation

OFF position

The pump will not run.

AUTO position

The pump will not run if the pressure is above the Set Pressure. The pump will start automatically if the pressure drops below the Set Pressure less the Start Diff. Press. Example: If the Set Pressure is 40 PSI, and the Start Diff. Pressure is 5 PSI. The pump will start when the pressure drops below 35 PSI (see example below).



Pressure Transducer Fail Shutdown

In the event that the pressure transducer signal should be lost, the system will shut the pump off. During the transducer fail error, the display will flash "SENSOR FAILURE" on the main display and the fault indicator will illuminate. If the transducer failure is corrected, the display will return to its normal condition and normal pressure control will resume.

Parameter Setup List

| SETTING DESCRIPTION | RANGE | DEFAULT |
|-------------------------|-------------------------------|------------------------------|
| Set Pressure | 0 to "Xducer Max Range" - 0.1 | 60.0 PSI |
| Start Diff. Pressure | 0 to "Set Pressure" - 1 | 5 PSI |
| Motor OL Amps | 0 to VFD Amp Rating | Model Specific |
| Motor Voltage | 0 to 1000 Volts | Model Specific (230/460 VAC) |
| Sleep Frequency | 0 to "Max Frequency" | 35.0 Hz |
| Sleep Time | 0 to 3600 seconds | 10 seconds |
| Xducer Max Range | 0 to 1000 PSI | 200 PSI |
| Min Frequency | 0 to "Max Frequency" | 30.0 Hz |
| Max Frequency | "Min Frequency" to 120 Hz | 60.0 Hz |
| PID Proportional Term | 0.1 to 1000% | 100.0% |
| PID Integral Term | 0.1 to 3600 seconds | 1.0 seconds |
| 1st Accel Time | 0 to 3600 seconds | 2 seconds |
| 1st Decel Time | 0 to 3600 seconds | 2 seconds |
| Accel 2 Switchover Freq | 0 to "Max Frequency" | 30 Hz |
| Accel/Decel Time | 0 to 3600 seconds | 3 seconds |
| High Pressure Alarm | 0 to "Xducer Max Range" - 0.1 | 90.0 PSI |
| Run Dry Pressure | 0 to "Set Pressure" - 1 | 15 PSI |
| Run Dry Delay Time | 0 to 6.0 minutes | 0.5 minutes |
| Run Dry Restart Time | 0 to 999.9 minutes | 0.0 minutes (manual restart) |

Parameter Setup List

Set Pressure

Set Pressure is the target pressure to be maintained at the pump discharge. It cannot exceed the maximum range of the pressure transducer.

Start Diff. Pressure

The Start Diff. Pressure is the amount of pressure drop from the Set Pressure, at which the VFD will wake from sleep and run to maintain the system pressure. The pump will start if the pressure drops below the Set Pressure less the Start Diff. Pressure. Example: If the Set Pressure is 40 PSI and the Start Diff. Pressure is 5 PSI, the pump will start when the pressure drops below 35 PSI.

Motor OL Amps

The VFD's electronic overload will signal an overload fault and protect the motor from damage in the event of an overload condition. Set the Motor OL Amps setting to the motor nameplate Full Load Amps for non-submersible pumps and to the Motor Max Amps for submersible pumps.

Motor Voltage


Set the Motor Voltage setting to the voltage rating found on the motor nameplate. This value must not exceed the voltage of the incoming power.

Sleep Frequency

Set the Sleep Frequency to the frequency at which the pump no longer builds pressure when operating at or near the Set Pressure. The VFD will enter the "sleep" mode when the output frequency of the VFD drops below the Sleep Frequency for a period of time (Sleep Time).

Sleep Time

Set the Sleep Time to the amount of time that the VFD will wait before entering "Sleep" mode after the output frequency drops below the Sleep Frequency. Note: If the system cycles on and off too frequently, try the following: increase the Sleep Time, lower the Sleep Frequency, or increase the Start Pressure. A combination of changes of all three settings may be necessary. If the VFD does not enter "Sleep" mode when there is no flow of water in the system, the Sleep Frequency must be increased.



Xducer Max Range

If using a different transducer other than supplied, set the Xducer Max Range to the full span rating of the pressure transducer. The Set Pressure and Start Diff. Pressure values must also be updated after changing the Xducer Max Range, as these values are automatically scaled based on the Xducer Max Range.

Min Frequency

The Min Frequency should be set to the minimum output frequency that the pump should be allowed to run. Contact your pump manufacturer to obtain the pump safe operation ranges.

Parameter Setup List

Max Frequency

The Max Frequency should be set to the maximum output frequency that the pump should be allowed to run. Contact your pump and motor manufacturer for operation above 60 Hz.

PID Proportional Term

The PID Proportional Term is intended to be adjusted by **advanced** users only. The PID Proportional Term is used to adjust the reaction of the output frequency to changes in the system pressure. Decreasing the PID Proportional Term will allow the VFD to make larger corrections to the output frequency with differences between the Set Pressure and actual system pressure. Increasing the PID Proportional Term will allow the VFD to make smaller corrections to the output frequency with differences between the Set Pressure and actual system pressure.

PID Integral Term

The PID Integral Term is intended to be adjusted by **advanced** users only. The PID Integral Term is used to adjust how quickly the output frequency reacts to changes in the system pressure. Decreasing the PID Integral Term will allow the VFD to make quicker corrections to the output frequency with differences between the Set Pressure and actual system pressure. Increasing the PID Integral Term will allow the VFD to make slower corrections to the output frequency with differences between the Set Pressure and actual system pressure.

1st Accel Time

Set the 1st Accel Time to the rate at which the output frequency will accelerate from 0 Hz to the Accel 2 Swithchover Frequency. This time is based on the time the VFD would take to accelerate from 0 Hz to 60 Hz. Example: If the pump is required to accelerate from stop to 30 Hz in 1 second the 1st Accel Time should be set to 2 seconds.

1st Decel Time

Set the 1st Decel Time to the rate at which the output frequency will decelerate from the Accel 2 Swithchover Frequency to a stop. This rate is based on the time the VFD would take to decelerate from 60 Hz to 0 Hz. Example: If the pump is required to decelerate from 30 Hz to a stop in 4 seconds the 1st Decel Time should be set to 8 seconds.

Accel 2 Swithchover Frequency

The Accel 2 Swithchover Frequency should be set to the frequency at which the acceleration and deceleration rates change. This is typically used on submersible type pumps, where the manufacturer requires a fast acceleration from a stop to 30 Hz for proper thrust bearing operation.

Accel/Decel Time

Set the Accel/Decel Time to the rate at which the output frequency will change as the VFD is operating above the Accel 2 Swithchover Frequency. This time is based on the time the VFD would take the accelerate or decelerate between 0 Hz to 60 Hz.

High Pressure

Set the High Pressure Alarm setting to the pressure at which the VFD output will shut off due to high system pressure. There is a 2 second delay before the VFD will activate the High Pressure Alarm. If system pressure drops below the High Pressure alarm setting for 10 seconds, the high pressure alarm will automatically reset and normal operation of the VFD will resume.

Run Dry Pressure

Set the Dry Run Pressure to the low pressure setting that will indicate the pump cannot build pressure due to the lack of supply water. The VFD must be running at maximum output frequency and the system pressure must be below the Dry Run Pressure for the amount of time set in Dry Run Delay Time for the VFD to stop due to a Dry Run Alarm.

Run Dry Delay Time

Set the Dry Run Delay Time to the amount of time the VFD must be running at maximum output frequency while the system pressure is below the Dry Run Pressure, before the VFD will stop due to a dry run alarm.

Run Dry Restart Time

Set the Dry Run Restart Time to the amount of time the VFD will remain stopped due to a Dry Run alarm, before restarting. This time allows the well or water source to "recharge" before the system restarts. If a manual restart is desired, set the Dry Run Restart Time to "0.0". For a manual restart of the system, the "ESC" button must be pressed for 2 seconds, or the power must be cycled. The display will indicate "Dry Run Fault" if a manual restart is required.

Pressure Tank/Pressure Relief Valve/Low Pressure

To maintain constant pressure and prevent frequent startup, a small-capacity pressure tank is needed in the system (refer to the minimum capacity of pressure tank table below). The VARIOspeed® N1 controller may use a pressure tank of a larger capacity than listed on the table below.

Minimum Capacity of Pressure Tank

| Flow Rate (GPM) | Tank Size (Total Capacity) |
|-----------------|----------------------------|
| Less than 12.0 | 4 Gallons |
| More than 12.0 | 8 Gallons |
| More than 50.0 | 14 Gallons |

Pre-Charge Pressure

1. Initial charge pressure should be set at 70% of the system pressure (Set pressure).
2. To maintain the optimum pressure control, check the air pressure in the tank regularly.

| Set Pressure (PSI) | Initial Charging Pressure (PSI) |
|--------------------|---------------------------------|
| 50 (default) | 35 |
| 55 | 39 |
| 60 | 42 |
| 65 | 46 |

A Pressure Relief Valve Must be Installed.

A pressure relief valve **MUST** be installed as close as possible to the pump discharge and plumbed to a drain able to handle the full flow of the pump in the event of a malfunction.

WARNING!

Failure to use a pressure relief valve could result in burst pipes and flooding if a system failure should occur.

Faults, Alarms and Warning Codes

| MAIN DISPLAY MESSAGE | DESCRIPTION OF FAULT ALARM |
|----------------------|---|
| COMMUNICATION LOST | Loss of Communications |
| SENSOR FAILURE | Pressure Sensor Fault |
| HIGH PRESS WARNING | High Pressure Warning |
| RUN DRY WARNING | Run Dry Warning (Automatic Reset) |
| RUN DRY FAULT | Run Dry Fault (Manual Reset required) |
| OVER CURR ACCEL | E.OC1 Overcurrent Trip During Acceleration |
| OVER CURRENT | E.OC2 Overcurrent Trip During Constant Speed |
| OVER CURR DECEL | E.OC3 Overcurrent Trip During Deceleration |
| OVER VOLTAGE 1 | E.OV1 Regenerative Overvoltage |
| OVER VOLTAGE 2 | E.OV2 Regenerative Overvoltage |
| OVER VOLTAGE 3 | E.OV3 Regenerative Overvoltage Trip |
| VFD OVERLOAD TRIP | E.THT Inverter Overload Trip |
| MOTOR OVERLOAD TRIP | E.THM Motor Overload Trip |
| VFD OVERHEAT | E.FIN Fin Overheat |
| STALL PREVENTION | E.OLT Stall Prevention |
| GROUND FAULT | E.GF Output Side Earth (ground) |
| OUTPUT PHASE LOSS | E.LF Output Phase Loss |
| INRUSH CURRENT LIMIT | E.IOH Inrush Current Limit Circuit |
| INVALID ANALOG INPUT | E.AIE Analog Input Fault |
| INPUT PHASE LOSS | E.ILF Input Phase Loss |
| BRAKE XSTR ALARM | E.BE Break Transistor Alarm Detection |
| XTRNL THERMAL OVLD | E.OHT External Thermal Relay Operation |
| XTRNL THERMIST TRIP | E.PTC PTC Thermistor Operation |
| VFD EEPROM FAULT | E.PE Parameter Storage Device Fault |
| DISCONNECTED PU | E.PUE PU Disconnection |
| FAULT RETRY EXCEEDED | E.RET Retry Count Excess |
| VFD CPU FAULT | E.5/E.CPU CPU fault |
| OUTPUT AMPS DETECT | E.CDO Output Current Detection Value Exceeded |
| SAFETY CIRCUIT FAULT | E.SAF Safety Circuit Fault |

IMPORTANT:

Faults can be reset by pressing the STOP/RESET button on the VFD. The OFF/AUTO selector switch must be in the "OFF" position when resetting any fault. Please contact your distributor if you are unable to reset a fault by removing power from the VFD and repowering after one minute.

Viewing Log

Viewing Pump Motor Run Time

Pump Motor Run Time

1234567 hours

The accumulated run time of the motor can be viewed by accessing the View Run Time screen in the setting menu. The run time is displayed in total hours run.

Viewing VFD Fault History

VFD OVERLOAD TRIP
STALL PREVENTION
VFD OVERLOAD TRIP
VFD OVERLOAD TRIP

The VFD fault history can be viewed by accessing the VFD Fault History screen in the settings menu. The last eight faults can be viewed by scrolling through the VFD Fault History screen, with the most recent faults first. If a fault is currently active, the fault will flash on the main screen.


Viewing System Fault Log

-- Time Since Fault --
H. Press 42d 16:23:42
Run Dry No Faults
Sensor No Faults

The System Fault Log can be viewed by accessing the View Sys Fault Log screen in the settings menu. The System Fault Log shows the length of time since a HIGH PRESSURE CONDITION, RUN DRY CONDITION, or SENSOR FAILURE occurred. If no fault has occurred, the "No Faults" message is shown.

Terminal Connections


240 VAC CONTROLLERS




NOTE: When connecting single-phase power, use terminals L1 and L2 only.

Terminal L3 is left unused.

480 VAC CONTROLLERS



Installation



Notes: _____

Notes: _____

Notes:



SJE RHOMBUS.®

Technical support: +1 800-746-6287

techsupport@sjeinc.com

www.sjerhombus.com

Technical Support Hours: Monday-Friday, 7 A.M. to 6 P.M. Central Time

BN 1041318E 01/20

© 2020 SJE, Inc. All Rights Reserved.
SJE RHOMBUS is a trademark of SJE, Inc.